
ADJUSTING YOUR KAYAK'S FOOT BRACES

The ASCEND® kayak foot brace system makes it easy to adjust your pedal position while seated. The foot braces have been customized to fit your particular boat for maximum comfort.

PEDAL ADJUSTMENT

The design allows you to easily adjust the foot braces up to 15" (38.10 cm). Simply pull the lever to release the lock. The foot brace will slide freely to the desired position. Release the lever to lock the foot brace in place.



The adjustment lever can be pulled toward you with the opposite foot to create hands-free adjustment, if necessary.

